CUlight FR36C Hinweise zur Aktualisierung der Firmware

1. Bitte aktualisieren Sie die Firmware mit der CUlight Firmware Update Software FR36. Die Software kann unter www.cullmann.de heruntergeladen werden.
2. So überprüfen Sie Ihre Firmware-Version: Drücken Sie den „Modus“ Knopf und schalten Sie das Blitzgerät ein. Die Updateversion der Firmware (z.B. Version xx sieht so aus: U-xx) wird auf dem LC Display angezeigt.
3. Hinweise zu den Versionen

Version	aktualisierte Inhalte
V.1.2	Fügt im C.Fn Menu eine Wireless-ID hinzu und erhöht so die störungsfreie Funkübertragung.
V1.1	Optimiert die Unterstützung der Canon Kameras M3/M5/M6

CUlight FR 36C Firmware Instructions

1. Please update the firmware with CUlight Firmware Update Software FR36. It can be downloaded on the official website.
2. Firmware Version Checking: Press the “Mode” button and turn on the camera flash. The firmware update version (e.g. Version xx will read U-xx) will be displayed on the LCD panel.
3. Version Instructions:

Version	Updated Contents
V.1.2	To add wireless ID in C.Fn menu, thus increasing the noninterference of wireless transmission.
V1.1	The original version.